

## Crosley Corp.

**Model:** TRIRDYN

**Chassis:**

**Year:** Pre 1932

**Power:**

**Circuit:**

**IF:**

**Tubes:**


**Bands:**

Resources

**Riders Volume 1 - CROSLEY 1-16**

MODEL TRIRDYN  
 MODEL 51  
 MODEL 5-38  
 Schematic

CROSLLEY RADIO CORP.



MODEL 5-38

Model 5-38, Series 2 (Serial No. 8000H & Above)


BELOW 8000H 4TH TUBE IS 2RF, 5TH TUBE DET

- |      |     |    |      |    |    |
|------|-----|----|------|----|----|
| 1 RF | 01A | OR | X'39 | OR | 1Z |
| 2 AF | 01A | OR | X'39 | OR | 1Z |
| 1 AF | 01A | OR | X'39 | OR | 1Z |
| DET  | 01A | OR | X'39 | OR | 1Z |
| 2 RF | 01A | OR | X'39 | OR | 1Z |

FRONT

Model Trirdyn


MODEL 51



Model 51

- |     |     |    |      |    |    |
|-----|-----|----|------|----|----|
| DET | 01A | OR | X'39 | OR | 1Z |
| AF  | 01A | OR | X'39 | OR | 1Z |

FRONT



Crosley Model 51 Circuit

MODEL TRIRDYN